



Note: 1) The PV CT is installed in the phase line (brown) on the incoming side of the M-RELAY, with the arrow pointing upwards towards the M-RELAY.
 2) The battery CT is mounted on the phase line (brown) above QF5 with the arrow pointing to QF4.

MC100-T wire diagram